

TOILET BUNG

USER GUIDE



The U bend Toilet Bung is a simple inflatable device that can be used to minimise the risk of sewage backflow through the toilet under flood conditions.

When fitted in a toilet U bend, this product has been proven to reduce the risk of sewage backflow significantly.



PRE FLOOD

- Gently push the deflated bag down into the toilet U bend below the water level.
- Remove the protective cap from the end of the hose.
- Prepare the hand pump by removing the flexible connector and fasten to end of the hand pump.
- Connect the hose to the other end of the flexible connector and commence pumping.
- Inflate the bung but be careful not to over-inflate it.
- Remove the pump from the hose and replace the protective cap to the hose to maintain inflation.

- It is advisable not to use the toilet whilst the bung is in place.
- For maintenance purposes, fully inflate the bung and leave for 24hrs. It is advised to undertake maintenance every 3 months.
- WARNING: Take care not to over inflate your toilet bung as this may cause it to rupture. Ensure the pump is removed after inflation.

POST FLOOD

- Once the threat of sewage backflow has subsided, remove the protective cap from the hose and release air from the bung by depressing the pin in the valve of the hose.
- Remove the bung and hose from the toilet.
- Ensure all parts are thoroughly cleaned before allowing to dry and store away.



FLOOD WATER IS USUALLY CONTAMINATED. APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT (PPE) MUST BE WORN AT INSTALLATION. IT IS ALSO ADVISABLE THAT PPE IS WORN WHEN HANDLING ANY FLOOD CONTAMINATED AREA.